



## Wireless Keyboard

### IC-KP08 Pro


## User Manual

Thank you for purchasing this iClever product.  
Before using the keypad, please read this user manual carefully and keep it for future reference.

### Package Contents

- 1 x Number Pad
- 1 x USB-C to USB-A Charging Cable
- 1 x Keypad Shortcut Icon Stickers
- 1 x User Manual

### Product Indicators



#### ① Power Indicator & Charging Indicator:

- Lights for 3 seconds when powered on
- Stays red while charging
- Turns off when fully charged

#### ② Bluetooth Indicator:

- Flashing blue: pairing mode
- Turns off after successful connection

#### ③ Number Lock Indicator:

Default setting: ON

- ON: keys type numbers
- OFF: keys act as navigation keys such as Home, End, Ins

**Note:** Num Lock works on Windows only.  
On macOS and iPadOS the keypad always types numbers.

### Quick Start

#### Step 1: Power On the Keypad

Slide the power switch to **ON**. The indicator lights for 3 seconds.

**Tip:** Ensure the keyboard is charged for 1 hours before first use.

#### Step 2: Enable Bluetooth on Your Device

Go to your device's **Settings**, select **"Bluetooth"** and turn it on.

#### Step 3: Pair the Keypad

1. Press **(Fn) + (ESC)** or **(Fn) + (TAB)** or **(Fn) + (INS)** to select channel 1, 2, or 3.

**Each channel can connect to one device**

2. Hold **(Fn) + (ESC)** or **(Fn) + (TAB)** or **(Fn) + (INS)** for 5 seconds to enter pairing mode. The indicator flashes blue.

3. Select **"iClever KP08 Pro"** in your Bluetooth list.

### Finding the "iClever KP08 Pro" on Different Systems

Device Type	Steps
Windows 10/11 (PC, laptop, tablet)	Open <b>Settings &gt; Devices &gt; Bluetooth &amp; other devices &gt; Add Bluetooth or other device &gt; Bluetooth &gt;</b> Select the keypad and click <b>Pair</b> .
macOS (Mac)	Go to <b>System Preferences &gt; Bluetooth</b> , Select the keypad and click <b>Pair</b> .
iOS/Android (Phone, iPad, Smartphone)	Open <b>Settings &gt; Bluetooth</b> , Select the keypad from the list and tap <b>Pair</b> .

### Troubleshooting Tips

#### Cannot find the device name?

- Ensure the keyboard is in pairing mode (indicator flashing fast).
- Confirm that Bluetooth is enabled and discoverable.
- Restart the keypad and your device.

#### Connected but not typing?

- Switch to the correct Bluetooth channel.

### Special Function Keys

	Description
	Turns number lock on or off. Works on Windows only. On macOS and iPadOS numbers always type.
	Used with other keys to enable special functions and Bluetooth controls.
	Press fn + this key to open the Calculator app on Windows. <b>No function on macOS or iPadOS.</b>
	Press fn + esc to switch to Bluetooth channel 1. Hold fn + esc for 5 seconds to enter pairing mode.
	Press fn + tab to switch to Bluetooth channel 2. Hold fn + tab for 5 seconds to enter pairing mode.
	Press fn + this key to switch to Bluetooth channel 3. Hold Fn + this key for 5 seconds to enter pairing mode. <b>Works as Print Screen.</b>

### Contact

Need Help? Contact Us

We're here to help.

If you have any questions or need support, please contact us:

Email: support@iclever.com

### Specifications

Connection Type	Bluetooth
Connected Device	up to 3 devices
Dimensions	132 x 89 x 20 mm
Weight	Approximately 100 g
Charge Time	About 1 hour via USB-C
Working Time	Up to 60 days per charge
Lithium Battery Capacity	100 mAh
Material	ABS + Aluminum
Frequency Band	2402MHz - 2480MHz
Maximum Transmission Power	0 dBm

### Compatibility

- Windows: 10, 11, or later (with Bluetooth HID Profile; PC/Laptop/Tablet)
- macOS: 10.15 or later (Mac/iMac)
- iPadOS: 14 or later (iPad)
- Android: 8.0 or later (Smartphone/Tablet)

#### Please Note:

1. This keypad may not work properly with Bluetooth adapters, Mac Mini, Samsung Smart TVs, or Nokia phones.
2. This keypad does not support wired connection.

### FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help  
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### Charging Instructions

Output: DC 5V/200mA;

**NOTE:** USB charger is not included in the package.


If the charger's voltage exceeds 7V, the keyboard will stop charging.

**English:** The power supplied by the charger must be between a minimum of 1 watt and a maximum of 5 watts to achieve the maximum charging speed.

**Deutsch:** Die vom Ladegerät gelieferte Leistung muss zwischen minimal 1 Watt und maximal 5 Watt liegen, um die maximale Ladegeschwindigkeit zu erreichen.

**Français:** La puissance fournie par le chargeur doit être comprise entre un minimum de 1 watt et un maximum de 5 watts pour atteindre la vitesse de charge maximale.

**日本語:** 充電速度を最大限にするため、充電器の出力は1ワット以上5ワット以下である必要があります。



## ワイヤレステンキー

### IC-KP08 Pro


## 取扱説明書

本製品をお買い上げいただき、誠にありがとうございます。  
ご使用前に本取扱説明書をよくお読みいただき、正しくお使いください。

### パッケージ内容

- テンキー本体 x 1
- USB-C充電ケーブル x 1
- 取扱説明書 x 1
- ショートカットキー用アイコンシール x 1

### 各部名称とインジケータ



#### ① 電源・充電インジケータ

- 電源オン時：約3秒間緑に点灯します
- 充電中：赤色に点灯します
- 満充電時：消灯します

#### ② Bluetoothインジケータ

- 青色点滅：ペアリングモード
- 接続完了後：消灯します

#### ③ Num Lockインジケータ

初期設定：ON

- ON：数字入力が可能
- OFF：Home/Endなどのナビゲーションキーとして動作

※ Num Lock機能はWindowsのみ対応  
macOS・iPadOSでは常に数字が入力されます

### ご使用方法

#### 1 電源を入れる

電源スイッチを**ON**にしてください。

インジケータが約3秒間点灯します。

※初回ご使用前に1時間以上充電することをおすすめします。

#### 2 デバイスのBluetoothを有効にする

ご使用の機器の設定から「Bluetooth」をオンにしてください。

#### 3 ペアリングします

①. **(Fn) + (ESC) / (TAB) / (INS)** を押しBluetoothチャネル1~3を選択。各チャネルは1台のみ接続できます。

②. **(Fn) + (ESC) / (TAB) / (INS)** を約5秒間長押しインジケータが青色点滅しペアリングモードになります。

③. Bluetoothリストで「iClever KP08 Pro」を選択してください。接続成功すると、インジケータが消灯します。

### 各OSでの接続方法

OS	接続方法
Windows 10/11	設定 → デバイス → Bluetooth → デバイスの追加 → Bluetooth一覧から選択してペアリング
macOS	システム設定 → Bluetooth一覧から選択して接続
iOS/Android	設定 → Bluetooth表示された一覧から選択して接続

### トラブルシューティング

#### デバイスが見つからない場合

- ペアリングモードになっているか確認 (青色点滅)
- Bluetoothがオンになっているか確認
- テンキーをご使用機器を再起動

### 機能キー説明

	説明
	Num Lockのオン/オフ切替 (Windowsのみ) macOS・iPadOSでは常に数字入力
	他のキーと組み合わせると機能操作やBluetooth切替を行います
	Fnキーとこのキーを同時に押すと、Windowsでは電卓アプリが起動します ※ macOS・iPadOSでは動作しません
	Fnキーとこのキーを同時に押すと、Bluetoothチャネル1へ切替 Fn + esc を約5秒長押ししてペアリングモード
	Fnキーとこのキーを同時に押すと、Bluetoothチャネル2へ切替 Fn + tab を約5秒長押ししてペアリングモード
	Fnキーとこのキーを同時に押すと、Bluetoothチャネル3へ切替 Fn + このキーを約5秒長押ししてペアリングモード Windowsではスクリーンショットとしても使用可能

### 省エネモード

2時間操作しない場合、キーボードが自動的にスリープモードに入ります。任意のキーを押すだけで再起動できます。  
なお、復帰時に約3秒程度の復帰時に約3秒程度の遅延が発生する場合がありますが正常な動作です。

### 仕様

接続方式	Bluetooth
接続可能台数	最大3台
製品寸法	132 x 89 x 20 mm
製品質量	約100 g
充電時間	約1時間 (USB-C)
連続使用時間	約60日
バッテリー容量	100 mAh
材質	ABS/アルミフレーム
周波数帯域	2402 MHz - 2480 MHz
最大送信電力	0 dBm

※ 本製品は有線接続には対応していません。

### 対応機種・OS

- Windows 8 以降のPC/ラップトップ
- Mac OS 10.12 以降のMac/iMac
- iOS 14.0 以降のiPhone/iPad
- Android 8.0 以降のスマホ/タブレット

一部のBluetoothアダプタ、Samsung Smart TV、Nokia phones、Linux、Mac mini、その他の不明な新しいAndroidデバイス、Bluetooth 4.0未満のデバイスには完全対応していません。

### カスタマーサービス

Eメール：support@iclever.co.jp

### よくあるご質問

#### Q：キーが勝手に入力される、または文字が連続して入力される

以下をご確認ください

1. ご使用のデバイスでBluetooth機能が有効になっているか確認してください
2. テンキーを再接続してください
3. ご使用のデバイスを再起動してください
4. 他のBluetooth機器や無線機器が近くにある場合、干渉が発生することがありますので距離を離してください
5. 他のBluetoothキーボードが同時に接続されていないか確認してください

※ 干渉が原因の場合は再接続により改善することがあります

#### Q：接続できない、ペアリングができない

以下を確認してください

1. ご使用のデバイスのBluetoothがオンになっているか確認してください
2. テンキーのバッテリーに十分な残量があるか確認してください
3. テンキーがペアリングモード (青色点滅) になっているか確認してください
4. Bluetoothリストから「iClever KP08 Pro」を削除し、再度登録してください
5. ご使用のデバイスを再起動してください

※ 一部のBluetoothアダプタや古いAndroidデバイスでは正常に動作しない場合があります

#### Q：充電ができない、フル充電してもすぐに電源が切れる

以下をご確認ください

1. 充電ケーブルが正しく接続されているか確認してください
2. USB充電器の出力が5Vであることを確認してください
3. 充電ポートにホコリや汚れが付着していないか確認してください
4. 充電ケーブルを変更して改善するか確認してください

※ 復帰時に約3秒程度の遅延が発生する場合がありますが異常ではありません

#### Q：Num Lockを押すとノートPCの入力が変わる

本製品のNum Lockキーは接続先デバイスのNum Lock状態と連動します。

WindowsノートPCの場合、Num Lockのオンオフにより、ノートPC側のキーボードが数字入力や方向キー入力に切り替わることがあります。異常ではありません。