

iclever

超薄型ワイヤレスキーボード
IC-BK15

取扱説明書

www.iclever.co.jp

パッケージの内容

1xキーボード
1xマイクロUSBケーブル
1x取扱説明書
1x保証カード

仕様

Bluetoothバージョン	Bluetooth 5.1
サイズ	373.5x129x17.56mm/ 14.7x 5.08x 0.69in
通信範囲	< 10 m / 32.8 ft
待機時間	90 日間
充電時間	< 2 時間
連続使用時間	90 時間
リチウム電池容量	280 mAh
キー寿命	300万回クリック
裏面材質	ステンレス・スチール
表面材質	ABS

インジケータ説明

① Fn ロックインジケータ: Fn + を同時に押すと、Fnキー機能が有効になります。Fn + を同時に押すと、Fn + ファンクションキーを同時に押さず、ファンクションキー (F1-F12) を押すと機能が有効になります。iOSのタブレットで検索するには「Fn + 」を押す必要があります。しかし、「」キーを押してFnキーがロックされた場合、「」を押すことにより機能が有効になります。

.1.

② Bluetooth LEDランプ: 接続状態の表示。

③ 電源インジケータ: 電源スイッチをオンにすると、緑色のランプが3秒点灯します。

④ 電源スイッチ: 右にスライドさせると電源が入ります。左にスライドすると電源が切れます。

⑤ マイクロ充電ポート: 充電専用。

キーボード機能

* AndroidまたはiOS (iPhoneとiPad) のショートカットキーを有効にするには、F1-F12キーを押すと有効になります。

* Windowsのタブレットで、ショートカットキーを有効にするには、F1-F12キーを押すと有効になります。Fn+F1-F12キーを同時に押すと、F1-F12機能が有効になります。

機能	iOS (F1-F12キーを押す)	Android (F1-F12キーを押す)	Windows Tablet (Fn + F1-F12キーを押す)	Windows PC (F1-F12キーを押す)
Esc	N/A	N/A	Fn ロック	Esc
	ホーム	ホーム	F1	ウェブブラウザ
	明るさダウン	明るさダウン	F2	明るさアップ (Windows 8以上)
	明るさアップ	明るさアップ	F3	明るさアップ (Windows 8以上)
	アプリケーション切り替え	アプリケーション切り替え	F4	アプリケーション切り替え
	N/A	バック	F5	N/A
	再生/一時停止	再生/一時停止	F6	再生/一時停止
	再生/一時停止	再生/一時停止	F7	再生/一時停止
	再生/一時停止	再生/一時停止	F8	再生/一時停止
	静音	静音	F9	静音
	ボリューム-	ボリューム-	F10	ボリューム-
	ボリューム+	ボリューム+	F11	ボリューム+
	スクリーンショット	スクリーンショット	F12	スクリーンショット

.2.

ペアリング手順

一台目のデバイスのペアリング

ステップ1. 電源スイッチをオンにします。電源インジケータが3秒ほど緑色に点灯します。

ステップ2. 「Fn」+ 「1」 キーを押すとチャンネル1に入り、 インジケータが青色で点滅します。

ステップ3. 「Fn」+ 「C」キーを同時に押すと、 インジケータが青色で点滅し、ペアリングモードに入ります。デバイスのBluetooth機能をオンにして、使用可能なデバイスを検索します。

ステップ4. 「Clever IC-BK15 Keyboard」という名のBluetoothキーボードをクリックして接続します。

ステップ5. 接続されると、 インジケータが青色に点灯します。

二台目のデバイスのペアリング

ステップ1. 「Fn」+ 「2」 キーを押すとチャンネル2に入り、 インジケータが青色で点滅します。

ステップ2. 「Fn」+ 「C」キーを同時に押すと、 インジケータが青色で点滅し、ペアリングモードに入ります。デバイスのBluetooth機能をオンにして、使用可能なデバイスを検索します。

.3.

ステップ3. 「Clever IC-BK15 Keyboard」という名のBluetoothキーボードをクリックして接続します。

ステップ4. 接続されると、 インジケータが青色に点灯します。

三台目のデバイスのペアリング

ステップ1. 「Fn」+ 「3」 キーを押すとチャンネル3に入り、 インジケータが青色で点滅します。

ステップ2. 「Fn」+ 「C」キーを同時に押すと、 インジケータが青色で点滅し、ペアリングモードに入ります。デバイスのBluetooth機能をオンにして、使用可能なデバイスを検索します。

ステップ3. 「Clever IC-BK15 Keyboard」という名のBluetoothキーボードをクリックして接続します。

ステップ4. 接続されると、 インジケータが青色に点灯します。

接続された三つのデバイスを切り替えるには?

「Fn」+ 「1」/ 「2」/ 「3」を同時に押して切り替えます。

接続されているチャンネルを再ペアリングするにはどうしたら良いですか?

チャンネル1 (またはチャンネル2または3) をデバイス1とすでに接続して、デバイス2をチャンネル1と接続したい場合、次の手順で操作してください。

ステップ1. 「Fn」+ 「1」 キーを押すとチャンネル1に入ります。

ステップ2. 「Fn」+ 「C」キーを同時に押すと、 インジケータが青色で点滅し、ペアリングモードに入ります。デバイスのBluetooth機能をオンにして、使用可能なデバイスを検索します。

ステップ3. 「Clever IC-BK15 Keyboard」という名のBluetoothキーボードをクリックして接続します。

ステップ4. 接続されると、 インジケータが青色に点灯します。

.4.

ご注意:

- 再接続機能: キーボードの電源をオンにする、最後に使用したデバイスと自動的に接続します。(接続デバイスのBluetooth機能をオンにしてください)
- ペアリングに失敗した場合は、デバイスからペアリング履歴を削除し、上記の手順を再度試してみてください。

キーボードの入力言語の切り替え

iOS 8、iOS 8以前のシステム: Win + Space
iOS 9、iOS 9以降のシステム: Ctrl + Space
Samsung Android: Shift + Space
Google Android: Ctrl + Space
Windows: Win + Space

重要事項—入力言語の設定

本製品は多国言語対応であるため、使用する前に利用したい入力言語に設定してください。

- iOSデバイスの場合
設定>一般>キーボード>キーボード>新しいキーボードを追加>使いたい言語を選択
- Androidデバイスの場合
設定>言語とキーボード>物理キーボード>キーボードレイアウト設定>使いたい言語を選択
- Windowsデバイスの場合
コントロールパネル>時間・言語・地域>使いたい言語を選択

.5.

対応するシステム

- iOS 6.0とOS 6.0以降のシステム
- Mac OS X v10.6, Mac OS X v10.12とそれ以後のシステム
- Windows XP / Vista / 7 / 8 / 10 搭載のパソコン (Bluetooth機能が必要)
- Android 3.0或いはそれ以後のシステム, Bluetooth HID profile機能付きなスマートフォンとタブレット
- このキーボードはSamsung Smart TV (UE37ES5500/UE55KU6400U/UE48JU6400)、Mac mini、Nokiaスマホには対応しません。

省エネモード

30分間操作しない場合、キーボードは自動的にスリープモードに入ります。再起動するには、いずれかのキーを押して、3秒ほどお待ちください。

充電の説明

- 付属されるUSBケーブルを使って充電してください。片方をUBSチャージャーに接続して、もう片方をキーボードに接続してください (出力: DC 5V/500mA。USBチャージャーは同梱されていません)。
- 充電中、電源インジケータが赤く点灯します。充電完了後、インジケータは消灯します。フル充電するまでは、約2時間程かかります。

.6.

FAQ (よくある質問)

1. 機器と接続できない

以下のような手順に従って操作してください。

- ✓キーボードBK15とお使いのデバイスを再起動し、機器のBluetooth接続記録を削除し、再接続してください。
- ✓お使いのデバイスのBluetooth機能がオンになっているかを確認してください。
- ✓お使いのデバイスのBluetoothをオフにした後、再度オンにしてください。
- ✓お使いのデバイスとキーボードBK15の距離をできる限り近づけてください。
- ✓キーボードBK15とお使いのデバイスをフル充電してください。

2. 日本語入力モードで、入力と出力の句読点異なる

IC-BK15キーボードは日本語 (JIS) ではなく、英語 (US) 配列ですので、入力と出力の句読点異なります。英語 (US) 入力モードに切り替える時、入力と出力の句読点が一致します。

3. 一部のファンクションキーが使えません

ファンクションキーを使用する前に、上記の「キーボード機能」をお読みください。相応するオペレーションシステムに切り替えられるかどうかを確認してください。(「Fn」)とQ / W / Eキーを押してiOS / Android / Windowsシステムに切り替えます)

4. キーの機能

キーはWindowsのWinキーまたはiOS / OS Xシステムのコマンドキーとしてどちらでも機能します。お使いのデバイスのシステムがWindowsの場合、キーはWinキーとして使用出来ます。お使いのデバイスのシステムがiOSまたはOS Xの場合、キーはコマンドキーとして使用出来ます。

カスタマーサービス:

Eメール: support@iclever.co.jp

.7.

iclever

Ultra Slim Rechargeable
Wireless Keyboard

IC-BK15

User Manual

www.iclever.com

Package Contents

1 x Wireless Keyboard
1 x Micro USB Cable
1 x User Manual
1 x Warranty Card

Specifications

Bluetooth Version	Bluetooth 5.1
Dimensions	373.5 x 129 x 17.56 mm / 14.7 x 5.08 x 0.69 in
Operating Range	< 10 m / 32.8 ft
Standby Time	90 days
Charging Time	< 2 hours
Uninterrupted Working Time	90 hours
Lithium Battery Capacity	280 mAh
Key Lifespan	3 million clicks
Front side of keyboard	Stainless steel
Back side of keyboard	ABS

Indicator Lights

① Fn Lock Indicator: Press Fn + keys simultaneously to activate the Fn lock function. When the Fn lock function is activated, you can press the F1-F12 function keys directly to use the corresponding hotkey functions.

② Bluetooth Indicator: For bluetooth connection status reminding.

.8.

③ Power Indicator: The power indicator will turn on and glow for 3 seconds once the keyboard has been turned on.

④ Power Switch: Flip the power switch to the ON position to turn on the keyboard and flip it to the OFF position to turn off the device.

⑤ Micro Charging Port: This port is for charging only.

Keys and Functions

Function	iOS (Press F1-F12 keys directly)	Android (Press F1-F12 keys directly)	Windows Tablet (Press Fn and F1-F12 keys)	Windows PC (Press F1-F12 keys directly)
Esc	N/A	N/A	Fn lock	Esc
	Home	Home	F1	Web browser or N/A
	Decrease brightness	Decrease brightness	F2	Decrease brightness (for Windows 8 devices or above)
	Increase brightness	Increase brightness	F3	Increase brightness (for Windows 8 devices or above)
	Switch APP	Switch APP	F4	Switch APP
	N/A	N/A	F5	N/A
	Previous track	Previous track	F6	Previous track
	Play/pause	Play/pause	F7	Play/pause
	Next track	Next track	F8	Next track
	Mute	Mute	F9	Mute
	Volume -	Volume -	F10	Volume -
	Volume +	Volume +	F11	Volume +
	Screenshot	Screenshot	F12	Screenshot
Search	Search	Search	Search	Search
	N/A	N/A		Share (for Windows 8 devices or above)
	N/A	N/A		Open wireless device (for Windows 8 devices or above)
	N/A	N/A		Settings (for Windows 8 devices or above)

.9.

Note. After connecting to your device, you must press the Fn + relative keys (Q for iOS, W for Android, E for Windows) to select the specific operating system, otherwise some of the keys' functions will not work.

Pairing Steps

How to pair with new devices

Pairing with the 1st device

Step 1. Flip the power switch to the ON position to turn on the keyboard, and the green indicator light will glow for 3s and then turn off automatically.

Step 2. Press Fn + keys to select channel 1, then the Indicator will flash blue.

Step 3. Press Fn + C keys to enter pairing mode, then the indicator will flash blue and will start to search for available Bluetooth devices.

Step 4. Locate the Bluetooth name "Clever IC-BK15 Keyboard" on your 1st device and click the name to connect it.

Step 5. The indicator will glow blue continuously after the keyboard has been paired successfully.

Pairing with the 2nd device

Step 1. Press Fn + keys to select channel 2, then the Indicator will flash blue.

Step 2. Press Fn + C keys to enter pairing mode, then the indicator will flash blue and will start to search for available Bluetooth devices.

Step 3. Find the Bluetooth name "Clever IC-BK15 Keyboard" on your 2nd device and click the name to connect it.

Step 4. The indicator will glow blue continuously after the keyboard has been successfully paired.

.10.

Pairing with the 3rd device

Step 1. Press Fn + keys to select channel 3, then the Indicator will flash blue.

Step 2. Press Fn + C keys to enter pairing mode, then the indicator will flash blue and will start to search for available Bluetooth devices.

Step 3. Find the Bluetooth name "Clever IC-BK15 Keyboard" on your 3rd device and click the name to connect it.

Step 4. The indicator will glow blue continuously after the keyboard has been successfully paired.

How to switch among 3 devices that are already connected

Press Fn and or or key to switch among devices.

How to re-pair a channel that is already connected

If you already connect channel 1 (or channel 2 or 3) with device 1, and you want to use another device to connect channel 1 (or channel 2 or 3), please do the following.

Step 1. Press Fn + keys to enter channel 1.

Step 2. Press Fn + C keys to enter pairing mode, then the indicator will flash blue and will start to search for available Bluetooth devices.

Step 3. Find the Bluetooth name "Clever IC-BK15 Keyboard" on your 3rd device and click the name to connect it.

Step 4. The indicator will glow blue continuously after the keyboard has been successfully paired.

Notes.

- Auto re-connect function, when you turn on the keyboard, it will connect with the last-used device automatically.
- If connection fails, delete the pairing record from your device, and follow the above instructions again.

.11.

How to set the keyboard language

This is a multilingual keyboard. Therefore, please set your desired languages for the keyboard before using.

- For iOS devices only :**
Settings > General > Keyboard > Keyboards > Add new keyboard > Select desired language
- For Android devices only :**
Settings > Language and input > Physical Keyboard > Set up keyboard layouts > Select desired language
- For Windows devices only :**
Control Panel > Clock, Language and Region > Select desired language

How to switch languages on the keyboard

iOS 8 or below : Win + Space
iOS 9 or above : Ctrl + Space
Samsung Android : Shift + Space
Google Android : Ctrl + Space
Windows : Win + Space

System Requirements

- iOS 6.0 and above
- Mac OS X v10.6 to Mac OS X v10.12 and above
- Windows XP / Vista / 7 / 8 / 10, PC computer with a Bluetooth host
- Android 3.0 and above with Bluetooth HID profile (Smartphones and Tablets)
- iOS 7.0 and above with Samsung Smart TV (UE37ES5500, UE55KU6400U, UE48JU6400), Mac mini and Nokia phones.

.12.

Power Saving Mode

The keyboard will enter sleep mode after being idle for 30 minutes. To activate it, press any key and wait for 3 seconds.

How to Charge it

- Use the included USB cable to charge the keyboard. Connect one end of the charging cable to a USB charger, and the other end to the charging port of keyboard. (Output, DC 5V/500mA; USB charger is not included.)
- The power indicator will glow red during charging process, and will turn off after the keyboard is fully charged. Generally, it takes approximately 2 hours for a full charge.

FAQ

1. My keyboard fails to connect.

If you can't successfully connect the keyboard to your device, please try the following.

- ✓ Restart both BK15 keyboard and your device, delete the connection record and re-pair it again.
- ✓ Check whether the Bluetooth function of your device is activated. Reactivate the Bluetooth function of your device.
- ✓ Minimize the distance between the BK15 keyboard and your device as much as possible.
- ✓ Fully charge both devices to ensure the pairing process won't be affected by low batteries.

2. Why is the Japanese punctuation of input and output different?

The IC-BK15 keyboard is based on US layout other than Japanese layout, hence the punctuation may be different when you select the Japanese input method. When you switch to the English (US) input method, the punctuation will be the same as the displayed layout.

.13.

3. Why do some function keys not work?

Before using the function keys, please read the above Function and Keys chart first. Additionally, please make sure you have already switched to the corresponding system by pressing Fn + Q/W/E.

4. What is the key function?

The key works as the win key in Windows operating system or the command key in iOS/OS X operating system.

Contact

For more questions, please feel free to contact us by support@iclever.com (US and EU).

.14.