

折り畳み ワイヤレス キーボード

IC-BK16

取扱説明書

www.iclever.jp


パッケージ内容

- 1×ワイヤレスキーボード
- 1×USB 充電ケーブル
- 1×取扱説明書
- 1×保証カード

仕様

Bluetoothバージョン	Bluetooth 5.0
通信範囲	< 10 m
待機時間	90日
充電時間	2時間
連続利用時間	80時間
リチウム電池容量	140mAh
キー寿命	300万回

LEDランプ



① Caps Lockランプ:

「Caps Lock」キーを押すと、大文字・小文字を切り替えられます。

Androidの場合、インジケータが点灯しないことがあります。Caps Lockキーの大文字・小文字を切り替え機能は通常通りに使用できます。

② Bluetoothインジケータ:

「Fn」+「C」キーを押すと、青で点滅、ペアリング完了すると自動的に消灯します。

③ 充電ランプ:

充電中：オレンジで点灯します；
充電完了：消灯。

④ 電源インジケータ:

キーボードを開くと、電源スイッチがオンになります。電源インジケータが緑で2秒ほど点灯して消灯します。

⑤ マイクUSB端子: 充電用

ペアリング手順

一台目のデバイスのペアリング

ステップ 1. 電源スイッチをオンにします。
ステップ 2. 「Fn」+「Q」キーを押すとチャンネル1に入ります。
ステップ 3. 「Fn」+「C」キーを同時に押すと、ステータスインジケータが青色で点滅し、ペアリングモードに入ります。

二台目のデバイスのペアリング

ステップ 1. 「Fn」+「W」キーを押すとチャンネル2に入ります。
ステップ 2. 「Fn」+「C」キーを同時に押すと、ステータスインジケータが青で点滅し、ペアリングモードに入ります。デバイスのBluetooth機能をオンにして、使用可能なデバイスを検索します。
ステップ 3. 表示画面にて「Clever IC-BK16 KB」を選択して接続します。
ステップ 4. 接続されると、ステータスインジケータが消灯します。

三台目のデバイスのペアリング

ステップ 1. 「Fn」+「E」キーを押すとチャンネル3に入ります。
ステップ 2. 「Fn」+「C」キーを同時に押すと、ステータスインジケータが青色で点滅し、ペアリングモードに入ります。デバイスのBluetooth機能をオンにして、使用可能なデバイスを検索します。
ステップ 3. 表示画面にて「Clever IC-BK16 KB」を選択して接続します。
ステップ 4. 接続されると、ステータスインジケータが消灯します。

B. 接続された三つのデバイスを切り替えるには？

「Fn」+「Q」/「W」/「E」を同時に押し切り替えることができます。

C. チャンネルの再設定をするにはどうしたら良いですか？

チャンネル1（またはチャンネル2または3）をデバイス1とすでに接続していて、他のデバイスをチャンネル1（またはチャンネル2または3）と接続したい場合、次の手順で操作してください。

ステップ 1. 「Fn」+「Q/W/E」キーを押すとチャンネル1（またはチャンネル2または3）に入ります。
ステップ 2. 「Fn」+「C」キーを同時に押すと、ステータスインジケータが青色で点滅し、ペアリングモードに入ります。デバイスのBluetooth機能をオンにして、使用可能なデバイスを検索します。
ステップ 3. 表示画面にて「Clever IC-BK16 KB」を選択して接続します。
ステップ 4. 接続されると、ステータスインジケータが消灯します。

ご注意:

- 自動接続：キーボードの電源をオンにする、最後に使用したデバイスと自動的に接続します。（接続デバイスのBluetooth機能をオンにしてください）
- ペアリングに失敗した場合は、デバイスからペアリング履歴を削除し、上記の手順を再度お試しください。

キーボード機能

* AndroidまたはiOSデバイスのファンクションキーを有効にするには、Fn+F1-F12キーを押すと有効になります。
* Windowsのタブレットの場合、ファンクションキーを有効にするには、Fn+F1-F12キーを押すと有効になります。
Windows/パソコンの場合、Fn+F1-F12キーを同時に押すと、F1-F12機能が有効になります。

ファンクションキー	iOS	Android	Windows	Windows
使用方法	Fn+を押す	Fn+を押す	Fn+を押す	Fn+Shift+を押す
	N/A	バック または N/A	N/A	F5
	検索	ブラウザ検索 または N/A	ブラウザ検索	F6
	曲戻し	曲戻し	曲戻し	F7
	再生/ 一時停止	再生/ 一時停止	再生/ 一時停止	F8
	曲送り	曲送り	曲送り	F9
	静音	静音	静音	F10
	ボリューム-	ボリューム-	ボリューム-	F11
	ボリューム+	ボリューム+	ボリューム+	F12
	削除	削除	削除	N/A

言語切り替え

iOS 8 or below: Win + Space
iOS 9 or above: Ctrl + Space
Android: Ctrl + Space / Shift + Space
Windows: Win + Space

スタンド内蔵

スマホとタブレットを立てられるスタンドが付いております。

重要事項—入力言語の設定

本製品は多国言語対応のため、使用する前に使いたい言語を登録してください。

iOSデバイスの場合:
設定>一般>キーボード>新しいキーボードを追加>使いたい言語を選択

Androidデバイスの場合:
設定>言語とキーボード>物理キーボード>キーボードレイアウト設定>使いたい言語を選択

Windowsデバイスの場合:
コントロールパネル>時間・言語・地域>使いたい言語を選択

充電の説明

- 付属されるUSBケーブルを使って充電してください。
- 充電中、電源インジケータがオレンジ色で点灯します。フル充電するまでは、約2時間程かかります。(出力: DC 5V/200mA)

FAQ

Q: 一部のファンクションキーが使えません
A: ファンクションキーを使用する前に、上記の「キーボード機能」をお読みください。


Q: 表示された符号は入力したものと異なる
A: キーボードは日本語 (JIS) ではなく、英語 (US) 配列のため、キーの表示と異なる符号が入力されてしまう場合があります。

Q: 「+ =」 ~ 「? /」 など 符号の入力方法:
A: 英語 (US) 入力状態で、Fn+対応するボタンを押すと入力できます。

Q: 「pgup, pgdn, home, end」の使用方法:
A: Fn+対応するボタンを押します。

カスタマーサービス:

Eメール: support@iclever.co.jp



Foldable Wireless Keyboard

IC-BK16

User Manual

www.iclever.jp


Package Contents

- 1× Wireless Keyboard
- 1× USB Charging Cable
- 1× User Manual
- 1× Warranty Card

Specifications

Bluetooth version	Bluetooth 5.0
Operating Range	Up to 10 meters
Stand-by time	3 months
Charging time	2 hours
Uninterrupted work time	80 hours
Lithium battery capacity	140mAh
Key life	3 million click

Indicator Light Description



① Caps lock indicator:

Press “Caps Lock” key to switch between uppercase and lowercase.
For Android Users, the Caps lock indicator may not be on but work as normal.

② Bluetooth Status Indicator:

Press “Fn” + “C” keys, it will flash blue, and it will be off after successfully paired.

③ Charging Indicator:

Stay in orange color when charging and turn off automatically after fully charged.

④ Power Indicator:

Move the button to the “ON” position to turn on the keyboard; power indicator will turn to be blue color for 2s then turns off.

⑤ Micro Charging Port:

Used for charging the keyboard.

Pairing Instruction:

A. How to pair with Bluetooth devices?

Pairing with the 1st device

Step 1. Move the button to the “ON” position to turn on the keyboard.
Step 2. Press “Fn”+“Q” keys simultaneously to enter channel 1.

Pairing with the 2nd device

Step 1. Press “Fn”+“W” keys simultaneously to enter pairing mode; status indicator will flash blue, starting to search the available Bluetooth device.
Step 2. Press “Fn”+“C” keys simultaneously to enter pairing mode; status indicator will flash blue, starting to search the available Bluetooth device.
Step 3. Find the Bluetooth name “Clever IC-BK16 KB” and click to connect it.
Step 4. The status indicator will be off after successfully paired.

Pairing with the 3rd device

Step 1. Press “Fn”+“E” keys simultaneously to enter channel 3.
Step 2. Press “Fn”+“C” keys simultaneously to enter pairing mode; status indicator will flash blue, starting to search the available Bluetooth device.
Step 3. Find the Bluetooth name “Clever IC-BK16 KB” and click to connect it.
Step 4. The status indicator will be off after successfully paired.

B. How to switch among 3 connected devices?

Press “Fn+ Q/W/E” key to switch.

C. How to re-pair a channel that has already been connected?

If you have already been connected channel 1/2/3 by device 1, and want to use other devices to re-pair channel 1/2/3, please do as following:

Step 1. Press “Fn+Q/W/E” keys simultaneously to enter channel 1/2/3.
Step 2. Press “Fn”+“C” keys simultaneously to enter pairing mode; status indicator will flash blue, starting to search the available Bluetooth device.
Step 3. Find the Bluetooth name “Clever IC-BK16 KB” and click to connect it.
Step 4. The status indicator will be off after successfully paired.

Notes.

- Auto re-connect function: when you turn on the keyboard, it will connect with the last-used device automatically.
- If connection fails, delete all the pairing records from your device, and follow the above instructions again.

Keys and Shortcut Function

For system of iOS, Android, use function keys by pressing Fn + F1-F12 keys; for system of Windows, use function keys by pressing Fn + F1-F12 keys, and use F1-F12 keys by pressing Fn + Shift + F1-F12 keys.

Switching the Keyboard Language

iOS 8 or below: Win + Space
iOS 9 or above: Ctrl + Space
Android: Ctrl + Space or Shift + Space
Windows: Win + Space

Hidden Holder Stands

With two hideable stands for holding the smartphone and tablet.

Important

As this is a multilingual keyboard, set the language of the device to your desired language before use.

- For iOS devices only:
Settings > General > Keyboard > Keyboards > Add new keyboard > Select desired language
- For Samsung Android devices only:
Settings > Controls > Language and input > Samsung Keyboard > Select input languages > Select desired language
- For Android devices only:
Settings > Language & input > Physical Keyboard > Set up keyboard layouts > Select desired language
- For Windows devices only:
Control Panel > Clock, Language and Region > Select desired language

System Requirements

- Windows version 8 and later
- Mac OSX 10.9 or later
- Apple, iPhone and iPad, iOS 9.0 or later
- Android OS tablet and smartphone, android 6.0 and above

Power Saving Mode

The keyboard will enter sleep mode after being idle for 10 minutes. To activate it, press any key and wait for 3 seconds.

How to Charge it

- Use the included USB cable for charging. Connect one end to a USB charger, and the other to the keyboard. (USB charger is not included)
- In charging, the power indicator will turn to be orange color. Generally, it takes approximately 2 hours for a full charge. (Output: DC 5V/200mA)

FAQ

I can't pair the keyboard with my device.
Your keyboard only connects to Bluetooth wireless-enabled devices. Confirm that the device you're trying to pair with is Bluetooth wireless-capable.

Contact:

For more question, please free to contact us by support@iclever.co.jp

If you can't successfully connect the keyboard to your device, please try as following:

- Ensure the device you're trying to pair with is Bluetooth wireless-capable.
- Charge keyboard for 10 minutes.
- Delete all the connection records.
- Turn off the Bluetooth function on your devices and turn it on again.
- Minimize the distance between the keyboard and your device as close as possible (30cm).
- Restart the device and try pairing it with the keyboard again.

Q: Why do some function keys not work?

A: Before using the function keys, please read above “Keys and Shortcut Function” chart first.

Q: Why the character of input is different to output?

A: Please ensure your input method is in English(US). Under Japanese input method, the character will be different.

Q: How to type these characters out(+ = ~ ? /) ?

A: Switch the input method to English (US), and then press fn + corresponding button.