

iclever  
Foldable Wireless Keyboard  
IC-BK06 Mate Keyboard  
User Manual  
www.iclever.com

Package Contents  
1 x Wireless Keyboard  
1 x Micro USB Cable  
1 x Stand Holder  
1 x User Manual  
1 x Warranty Card  
Specifications  
Bluetooth Specification Bluetooth 5.1  
Dimensions (open) 291x100x7mm  
Operating Range 8m  
Charge Time 2 hours  
Uninterrupted Work Time 60 hours  
Stand-by Time 90 days  
Key Life 3 million clicks  
Indicator Lights Description  
① Indicator : stay in red when charging, flash blue when in pairing mode, flash red quickly when low power.  
② Connect button : click to enter pairing mode, and indicator will keep flashing blue.  
③ Micro charging port : for charging.

Keys and Function  
The table below describes special key combinations for different operating systems.  
Function Keys iOS Android Windows 10 Mac OS Windows or Mac OS  
Way to use Press fn + Press fn + Press fn + Press fn + Press fn +  
Home Home or N/A Web Browser N/A esc  
Brightness + Brightness + Brightness + Brightness - F1  
Brightness - Brightness + Brightness + Brightness + F2  
Search Search or N/A Search Search F3  
Previous Track Previous Track Previous Track Previous Track F4  
Play/Pause Play/Pause Play/Pause Play/Pause F5  
Next Track Next Track Next Track Next Track F6  
Mute Mute Mute Mute F7  
Volume + Volume + Volume + Volume - F8  
Volume - Volume + Volume + Volume + F9  
Battery Checking Battery Checking Battery Checking Battery Checking F10  
Print Screen Print Screen or N/A Print Screen Print Screen F11  
Lock Screen Lock Screen or N/A Lock Screen N/A F12  
Delete Delete Delete Delete N/A

Special Keys Descriptions  
The fn key is used in combination with other keys to access special features.  
Press fn + this key to choose Bluetooth Channel 1.  
Press fn + this key to choose Bluetooth Channel 2.  
Press fn + this key to choose Bluetooth Channel 3.  
Press "connect" button to enter Bluetooth pairing mode.  
Press fn + this key to work as virtual keyboard. Note: this function work for iOS only.  
Press Fn + [ ] to work as page up.  
Press Fn + [ ] to work as page down.  
Press Fn + [ ] to work as home.  
Press Fn + [ ] to work as end.  
Press fn + this key to check the battery reminding. The Indicator flashes once for 25%, twice for 50%, 3 times for 75%, and 4 times for 100%.

Quick Start  
Step 1. Unfold the keyboard to power on.  
Step 2. Press "Fn"+"Q" keys to choose Bluetooth Channel 1.  
Step 3. Press button of "connect" to enter pairing mode; status indicator will flash blue slowly.  
Step 4. On your device, find the Bluetooth name "Clever IC-BK06 Mate Keyboard" and click to connect it.  
Step 5. The status indicator will be off after successfully paired.

Pairing Instruction  
A. How to pair with 3 devices?  
Pairing with the 1st device  
Step 1. Unfold the keyboard to turn on.  
Step 2. Press "Fn"+"Q" keys simultaneously to choose Bluetooth channel 1.  
Step 3. Press left button of "connect" to enter pairing mode; status indicator will flash blue slowly.  
Step 4. On your device, find the Bluetooth name "Clever IC-BK06 Mate Keyboard" and click to connect it.  
Step 5. The status indicator will be off after successfully paired.  
Pairing with the 2nd device  
Step 1. Press "Fn"+"W" keys simultaneously to choose Bluetooth channel 2.  
Step 2. Press button of "connect" to enter pairing mode; status indicator will flash blue slowly.  
Step 3. On your device, find the Bluetooth name "Clever IC-BK06 Mate Keyboard" and click to connect it.  
Step 4. The status indicator will be off after successfully paired.  
Pairing with the 3rd device  
Step 1. Press "Fn"+"E" keys simultaneously to choose Bluetooth channel 3.  
Step 2. Press button of "connect" to enter pairing mode; status indicator will flash blue slowly.  
Step 3. On your device, find the Bluetooth name "Clever IC-BK06 Mate Keyboard" and click to connect it.  
Step 4. The status indicator will be off after successfully paired.  
Notes:  
1. Auto re-connect function: when you turn on the keyboard, it will connect with the last-used device automatically.  
2. If the connection fails, please delete all the pairing records from your device, turn off your device Bluetooth function and turn it on again and then follow the above instructions again.  
B. How to switch among 3 connected devices?  
Press key of "fn"+"Q/W/E" to switch among connected devices.

C. How to re-pair a channel that has already been connected?  
If you have already been connected channel 1/2/3 by device 1 and want to use other devices to re-pair channel 1/2/3, please do as follows:  
Step 1. Press "Fn"+"Q/W/E" keys simultaneously to choose Bluetooth channel 1/2/3.  
Step 2. Press left button of "connect" to enter pairing mode; status indicator will flash blue slowly.  
Step 3. On your device, find the Bluetooth name "Clever IC-BK06 Mate Keyboard" and click to connect it.  
Step 4. The status indicator will be off after successfully paired.  
Keyboard Language Switching  
IOS 8 or below: command + space  
IOS 9 or above: ctrl + space  
Android: ctrl + space / shift + space / others  
Windows: 10: command + Space or alt + shift / caps Lock  
Note: for android devices, the above way may not work in all android devices.  
Important  
As this is a multilingual keyboard, set the language of the device to your desired language before use.  
For IOS devices only:  
Settings > General > Keyboard > Keyboards > Add new keyboard > Select desired language  
For Samsung Android devices only:  
Settings > Controls > Language and input > Samsung Keyboard > Select input languages > Select desired language  
For Android devices only:  
Settings > Language & input > Physical Keyboard > Set up keyboard layouts > Select desired language  
For Windows devices only:  
Control Panel > Clock, Language and Region > Select desired language

System Requirements  
\* IOS 6.0 and above  
\* Mac OS X 10.6 to Mac OS X 10.12 and above  
\* Windows XP/Vista/7/8/10, PC computer with a Bluetooth host  
\* Android 3.0 and above with Bluetooth HID profile  
(Smart phones and tablets)  
\* This keyboard is not compatible with Samsung Smart TV, Mac mini, iPad mini 5, Xbox, and Nokia phones.  
Power Saving Mode  
The keyboard will enter sleep mode after being idle for 10 minutes. To activate it, press any key and wait for 3 seconds.  
Charging the Keyboard  
\* Use the included USB cable for charging. Connect one end to a USB charger, and the other to the keyboard.  
(Output: DC 5V/80mA; USB charger is not included.)  
\* In charging, the power indicator will turn red. Generally, it takes about 2 hours for a full charge.  
FAQ  
Q: Fail to connect.  
Step 1. Before to connect, please set as below:  
\* Charge Clever Bluetooth keyboard for 30 minutes.  
\* On your device, delete/remove/forget the previous connection record with "Clever IC-BK06 Mate Keyboard".  
\* On your device, turn Bluetooth off, and turn Bluetooth on again.  
\* Make sure that your iclever device and computer are within close proximity of each other.  
Step 2. Follow the Pairing Instruction to connect it again.

Q: My iclever Bluetooth keyboard frequently gets disconnected or laggy.  
1. Restart your Bluetooth product.  
2. Charge iclever Bluetooth keyboard for 30 minutes. Low battery power can adversely affect connectivity and overall functionality.  
3. Make sure that your iclever Bluetooth keyboard and computer are within close proximity of each other.  
4. Do not use on metal surfaces.  
5. Computer power supplies  
\* Any device that could emit wireless waves: Microwave, cordless phone, baby monitor, wireless speaker, garage door opener, WIFI router  
6. Try moving away from:  
\* Metal or metal wiring in the wall  
7. Try on a different computer/smartphone/tablet.  
If the problem still persists, you will need to follow specific steps based on your device OS(Windows/Mac OS). Please email us.  
More questions about using under Android devices.  
Android operating system is still not unified, and different manufacturer make different rule. For standard keyboard, because of rule change, the standard function may not work any more. If you are using under Android device and suffering some problems, please contact us.  
Contact  
For more questions, please contact us by support@iclever.com.

FCC Statement  
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
- Reorient or relocate the receiving antenna.  
- Increase the separation between the equipment and receiver.  
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
- Consult the dealer or an experienced radio/TV technician for help.  
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

iclever  
ワイヤレス折り畳みキーボード  
IC-BK06 Mate Keyboard  
取扱説明書  
www.iclever.co.jp

バッテリー内容  
1 x ワイヤレスキーボード  
1 x マイクロUSBケーブル  
1 x スタンドホルダー  
1 x 取扱説明書  
1 x 保証カード  
仕様  
Bluetoothバージョン Bluetooth 5.1  
使用サイズ 291x100x7mm  
受信距離 8m  
充電時間 2時間  
連続使用時間 60時間  
待機時間 90日  
キー寿命 300万回クリック  
インジケーター  
① LEDランプ: 充電中、LEDランプが赤色で点灯します。ペアリングモードに入る時、LEDランプが青色で点滅します。バッテリー残量不足時、赤色で点滅します。  
② connectボタン: ボタンをクリックすると、LEDランプが青色で点滅します。  
③ マイクロ充電ポート。

キーボード機能  
下記の表には、各オペレーティングシステム用特別なキーの組み合わせについて説明しています。  
使用方法 iOS Android Windows 10 Mac OS Windows 10 or Mac OS  
Home ホーム ホーム N/A esc  
明るさアップ 明るさダウン 明るさアップ 明るさアップ F1  
明るさダウン 明るさアップ 明るさアップ 明るさアップ F2  
検索 フラッシュ検索 あるいはN/A 検索 検索 F3  
曲戻し 曲戻し 曲戻し 曲戻し F4  
再生 /一時停止 再生 /一時停止 再生 /一時停止 再生 /一時停止 F5  
曲送り 曲送り 曲送り 曲送り F6  
静音 静音 静音 静音 F7  
ボリューム ボリューム ボリューム ボリューム F8  
ボリューム+ ボリューム+ ボリューム+ ボリューム+ F9  
バックライト 残量確認 バックライト 残量確認 F10  
スクリーンショットあるいはN/A スクリーンショット スクリーンショット F11  
スクリーンロックあるいはN/A スクリーンロック N/A F12  
カーソルの後を削除 カーソルの後を削除 削除 カーソルの後を削除 N/A

特別なキー 説明  
fnキーは様々な機能を果たするために、他のキーと組み合わせて使われます。  
「Fn」+「Q」キーを押すと、Bluetoothチャンネル1に入ります。  
「Fn」+「W」キーを押すと、Bluetoothチャンネル2に入ります。  
「Fn」+「E」キーを押すと、Bluetoothチャンネル3に入ります。  
「connect」ボタンを押すと、選択したチャンネルのペアリングモードに入ります。  
fn + Qを押すと、「仮想キーボード」として機能します。注: iOSのみ対応します。  
「Fn」+ [ ] を押すと、pageとして機能します。  
「Fn」+ [ ] を押すと、pageとして機能します。  
「Fn」+ [ ] を押すと、homeとして機能します。  
「Fn」+ [ ] を押すと、endとして機能します。  
fn + Qのキーを押すと、電池残量を確認できます。一瞬の点滅は25%の電量を示します。

クイックスタート  
ステップ1: キーボードを広げると電源が自動的にオンになります。  
ステップ2: 「Fn」+「Q」を押しながらBluetoothチャンネル1に入ります。  
ステップ3: 「connect」ボタンを押すと、Bluetoothチャンネル1が青色で点滅し、ペアリングモードに入ります。  
ステップ4: 画面上のデバイス名から「Clever IC-BK06 Mate Keyboard」をクリックして接続します。  
ステップ5: ペアリングされた後、LEDランプが点滅します。  
ステップ6: ペアリングされた後、LEDランプが点滅します。  
ステップ7: 「Fn」+「E」を押して、Bluetoothチャンネル2を選択します。  
ステップ8: 左側の「connect」ボタンを押すと、LEDランプがゆっくり青色で点滅し、ペアリングモードに入ります。  
ステップ9: 画面上のデバイス名から「Clever IC-BK06 Mate Keyboard」をクリックして接続します。  
ステップ10: ペアリングされた後、LEDランプが点滅します。  
ステップ11: 「Fn」+「W」を押して、Bluetoothチャンネル3を選択します。  
ステップ12: 左側の「connect」ボタンを押すと、LEDランプがゆっくり青色で点滅し、ペアリングモードに入ります。  
ステップ13: 画面上のデバイス名から「Clever IC-BK06 Mate Keyboard」をクリックして接続します。  
ステップ14: ペアリングされた後、LEDランプが点滅します。  
ステップ15: 「fn」+「Q」を押すと、電池残量を確認できます。一瞬の点滅は25%の電量を示します。

ペアリング手順  
1. 二目目デバイスとペアリング  
ステップ1. キーボードを広げると電源が自動的にオンになります。  
ステップ2. Fn+Qを押して、Bluetoothチャンネル1に入ります。  
ステップ3. 左側の「connect」ボタンを押すと、LEDランプがゆっくり青色で点滅し、ペアリングモードに入ります。  
ステップ4. 画面上のデバイス名から「Clever IC-BK06 Mate Keyboard」をクリックして接続します。  
ステップ5: ペアリングされた後、LEDランプが点滅します。  
2. 三目目デバイスとペアリング  
ステップ1. Fn+Eを押して、Bluetoothチャンネル2を選択します。  
ステップ2. 左側の「connect」ボタンを押すと、LEDランプがゆっくり青色で点滅し、ペアリングモードに入ります。  
ステップ3. 画面上のデバイス名から「Clever IC-BK06 Mate Keyboard」をクリックして接続します。  
ステップ4: ペアリングされた後、LEDランプが点滅します。  
3. 四目目デバイスとペアリング  
ステップ1. Fn+Wを押して、Bluetoothチャンネル3を選択します。  
ステップ2. 左側の「connect」ボタンを押すと、LEDランプがゆっくり青色で点滅し、ペアリングモードに入ります。  
ステップ3. 画面上のデバイス名から「Clever IC-BK06 Mate Keyboard」をクリックして接続します。  
ステップ4: ペアリングされた後、LEDランプが点滅します。  
注意:  
1. すでにペアリング済みの機能が問題にある場合、機器側の自動再接続設定や、機器設定機能が有効であれば、その機能を自動的に再接続します。  
2. 接続に失敗した場合、デバイスからペアリング履歴を削除し、上記の手順をもう一度試してください。

接続された3つのデバイスを切り替えるには?  
「Fn」+「Q」/「W」/「E」を同時に押し続けて切り替えることができます。  
チャンネルの再設定をすることはほとんどありませんが、チャンネル1またはチャンネル2またはチャンネル3と接続したい場合、次の手順で操作してください。  
ステップ1. 「Fn」+「Q」/「W」/「E」キーを押すとチャンネル1（またはチャンネル2またはチャンネル3）に入ります。  
ステップ2. 左側の「connect」ボタンを押すと、LEDランプがゆっくり青色で点滅し、ペアリングモードに入ります。  
ステップ3. 画面上のデバイス名から「Clever IC-BK06 Mate Keyboard」をクリックして接続します。  
ステップ4. ペアリングされた後、LEDランプが点滅します。  
言語切り替え  
IOS 8 or below: command + space  
IOS 9 or above: ctrl + space  
Android: ctrl + space / shift + space  
Windows 10: command + space or alt + shift / caps Lock  
Windows 10: command + space or alt + shift / caps Lock  
USBチャージャーは付属していません。  
\* 充電中、電源インジケーターが赤く点灯します。フル充電するまでは、約2時間程かかります。  
重要事項—入力言語の設定  
本製品は多言語対応のため、使用する前に使いたい言語を登録してください。  
IOSデバイスの場合  
設定—一般—キーボード—キーボード—新しいキーボードを追加—使いたい言語を選択  
Androidデバイスの場合  
設定—言語とキーボード—物理キーボード—キーボードレイアウト—使いたい言語を選択  
Windowsデバイスの場合  
コントロールパネル—時間—言語—地域—使いたい言語を選択

対応OS  
\* IOS 6.0又はそれ以後のバージョン  
\* Mac OS X 10.6 to Mac OS X 10.12以後  
\* Windows XP / Vista / 7 / 8 / 10 (Bluetooth機能あり)  
\* Android 3.0或いはそれ以後のシステム. Bluetooth HID profile機能が必要なスマートフォン/タブレット  
\* 本製品はSamsung Smart TV (UE37ES5500, UE55K6400U, UE48B16400, Mac mini, iPad mini 5, Nokiaスマホには対応していません。  
省エネモード  
10分間操作しない場合、キーボードは自動的にスリープモードに入ります。再起動するには、いずれかのキーを押して、3秒ほどお待ちください。  
充電の説明  
\* 付属されるUSBケーブルを使って充電してください。片方をUSBチャージャーに接続し、もう片方をキーボードに接続してください。(出力: DC 5V/80mA、USBチャージャーは付属していません。)  
\* 充電中、電源インジケーターが赤く点灯します。フル充電するまでは、約2時間程かかります。  
FAQ (よくある質問)  
Q: 接続と接続できない  
ステップ1. 下記の順番に従って操作してください。  
\* お使いのデバイスのBluetooth接続履歴「Clever IC-BK06 Mate Keyboard」を削除してください。削除後、お使いのデバイスを再起動してください。  
\* お使いのデバイスのBluetoothをオフにした後、再度オンにしてください。  
\* キーボードを30分充電してください。  
\* お使いのデバイスとキーボードの距離をできる限り近づけてください。(30cm以内)  
ステップ2. ペアリング手順に従って再接続してください。

Q: Bluetoothデバイスとの接続が切断される。また、接続が頻りに切断される。入力の遅延が起る。  
1. お使いのデバイスを再起動してください。  
2. キーボードを30分充電してください。バッテリー残量が少ないと、接続性と全体的な機能に悪影響が出ることがあります。  
3. お使いのデバイスとキーボードの距離をできる限り近づけてください。(30cm以内)  
4. ご使用の期間に金属やその他のワイヤレス信号源から遠ざけてください。(20cm以上)  
(例) 以下のものから遠ざけるようにします:  
\* 無線電波を放出するデバイス: 電子レンジ、コードレス電話、ベビーモニター、ワイヤレススピーカー、ゲーミングアンプ、Wi-Fiルーター  
\* コンピュータの電源  
\* 強いWi-Fi信号  
\* 金属または壁内の金属配線  
5. 表面が金属でできた机の上でキーボードを使用しないでください。  
6. 遅延の原因となる更新プログラムのバックグラウンドで実行されていないかを確認してください。  
7. オペレーティングシステム (OS) が最新であることを確認してください。  
8. 同様の問題が起るか、別のコンピューター/スマートフォン/タブレットで接続と入力をお試しください。  
Q: Androidデバイスのユーザー様へ  
Androidがオペレーティングシステムは多機能性があるため、標準キーボードに比べて、入力規則が変更される可能性があります。ご使用の途中に何か不明点がございましたら、お気軽に弊社までお問い合わせください。  
カスタマーサービス  
Eメール: support@iclever.co.jp

iclever  
ワイヤレス折り畳みキーボード  
IC-BK06 Mate Keyboard  
取扱説明書  
www.iclever.co.jp