iclever

ウルトラスリムフルサイズ 2.4Gキーボードとマウスセット

IC-BK22 Combo

取扱説明書

www.iclever.co.jp

この度はiClever製品をお選びいただきまして誠にありがとうございます。ご使用前にこの取扱説明書をよくお読みください。お読み頂いた後も大切に保管してください。

パッケージ内容

1 x ワイヤレスキーボード
1 x ワイヤレスマウス
1 x マイクロUSB 充電ケーブル
1 x 2.4G USBレシーバー
1 x 取扱説明書
1 x 保証カード

キーボード仕様

寸法	366 x 125 x 16,2 mm /14,4 x 4,9 x 0,64 in
接続可能な距離	< 10 m/32,8 ft
充電時間	< 2 時間
連続使用時間	90 時間
リチウム電池キャパシティー	280 mAh
キーの寿命	300万クリック
スタンバイー時間	90日

マウス仕様

寸法	107,5 x 60 x 27,5 mm / 4,23 x 2,36 x 1,08 in
接続可能な距離	< 10 m/32,8 ft
電源	2 x AAA バッテリー（含まれていません）
連続使用時間	160日
キーの寿命	300万回クリック
DPI	1000-1200-1600

製品の概要



① 電源スイッチ：電源をオン／オフにする
② 電源インジケーター：電源をオンになると、3秒程LEDランプが緑色で点灯します。
③ キャップロックインジケーター：キャップロックを有効するとき、キャップロックランプは緑色で点灯します。キャップロックをオフにする際、もう一度CapsLockキーを押してください。
（Androidシステムの場合、キャップロックインジケーターが点灯しないことがあります。）
④ 数字インジケーター：NumLockを有効するとき、数字インジケーターは緑色で点灯します。NumLockをオフにしたいとき、もう一度NumLockキーを押してください。
⑤ Fnロックインジケーター：Fn + Escを押してFn Lock機能が有効になり、Fn Lockインジケーターが青色に変わります。Fn Lock機能が有効になると、F1~F12を直接に押すとファンクションキーが有効になります。
Fn+Escを押してFn Lock機能が無効になり、Fn Lockインジケーターが消灯します。
⑥ 充電インジケーター：充電中は赤色で点灯します。充電完了になったら消灯します。
⑦ マイクロ充電ポート



① オン/オフスイッチ：マウスをオン/オフにします。
② ストレージスロット：バッテリー（2本AAA、含まれていません）を入れてください。
USBレシーバーはマウス本体に差し込んでいます。
③ DPI スイッチ：DPIスイッチ（上記の図③）を押すと、マウスの感度（1000、1200、1600）を調節することができます。
④ スクロールボタン

キーボード機能

windowsとMac OS X(Macbook/iMac)システムの場合、Fn+F1~F12を同時に押すとファンクションキーが有効になります。直接にF1~F12を押せばF1~F12機能が有効になります。
下記の表には、各オペレーティングシステム用特別なキーの組み合わせについて説明しています。

ファンクションキー	Fn+Windows	Windows	Fn+Mac OSX	Mac OSX
使用方法	Fn+を押す	直接に押す	Fn+を押す	直接に押す
Esc	Fnロック	Esc	Fnロック	Esc
F1	明るさダウン (Windows 10)	F1	明るさダウン	F1
F2	明るさアップ (Windows 10)	F2	明るさアップ	F2
F3	ウェブブラウザ	F3	N/A	F3
F4	検索	F4	N/A	F4
F5	電卓	F5	N/A	F5
F6	曲戻し	F6	曲戻し	F6
F7	再生/一時停止	F7	再生/一時停止	F7
F8	曲送り	F8	曲送り	F8
F9	静音	F9	静音	F9
F10	ボリューム-	F10	ボリューム-	F10
F11	ボリューム +	F11	ボリューム +	F11
F12	スクリーンショット	F12	スクリーンショット 或いは N/A	F12

注：Fn + F1~F12キーを同時に押すと、Fnロックが有効になり、Fnロックインジケーターが青色に変わります，Fnロックが有効になると、いずれのF1~F12キーを押して機能を有効になります．

ペアリング手順

ステップ1. 2.4G USBレシーバーをPCに差し込みます。
ステップ2. キーボードの電源スイッチをオンにします。
ステップ3. AAA 電池 2 本を(別売)をマウスに入れてください。マウスをオンにします。
ステップ4. 使用する準備ができました。
ステップ5. Fn + Q / W を押して、Mac/Windowsシステムを選びます。

接続が失敗した場合は、まずFAQをお読みください。また、以下の手順に従って操作してください。

A. キーボード再ペアリング:
ステップ1. キーボードをオンにします。
ステップ2. Esc + Q キーを同時に押すと、インジケーターが素早く緑色で点灯します。
ステップ3. 10秒以内でUSBレシーバーをコンピューターボードに差し込みます。
キーボードとレシーバーの距離が30cm以内に近づけてください。
ステップ4. 接続が成功した後、電源インジケーターが3回点滅してから消灯します。

B. マウス再ペアリング:
ステップ1. マウスをオフにして、2.4G USBレシーバーを取り外してください。
ステップ2. マウスの右ボタンとスクロールホイールボタンを同時に約3秒長押ししてください。そして、マウスの電源をONにします。
ステップ3. 10秒以内でレシーバーをコンピューターボードに差し込みます。
マウスとレシーバーの距離が30cm以内に近づけてください。

注意：再ペアリングが成功した場合、使用できます。失敗した場合、上記の手順を再度繰り返してください。

省エネモード

30分間操作しない場合、キーボードは自動的にスリープモードに入ります。
スリープモードを終了するには、いずれかのキーを押してあるいはマウスを動かしてください。

充電の説明

ステップ1. 付属されるUSBケーブルを使って充電してください。片方をUBSチャージャーに接続して、もう片方をキーボードに接続してください（出力：DC 5V/500mA 。USBチャージャーは同梱されていません）。
ステップ2. 充電中、電源インジケーターが赤く点灯します。フル充電するまでは、約2時間程かかります。

マウスのバッテリー交換

インジケーターライトが点灯していない場合、バッテリーが切れます。
ストレージスロットを開き、電池を交換してください。

FAQ

1. このキーボードはwindows、Mac OS Xに対応しますか？

はい、windows、Mac OS Xに対応しますが、Mac OS Xの場合では、ファンクションキー の機能がありません。

また、Windowsの場合では、ファンクションキー , , の機能がありますが、Mac OS Xの場合では、この機能がありません。

2. , , , の機能は？

Windowsシステムではwin、無変換、変換 及び NumLKとして機能します。
(Fn+Wを押してWindowsシステムに切り替えます)
Mac OS Xシステムではcommand、英数、かな 及びクリアとして機能します。
(Fn+Qを押してMac OS Xシステムに切り替えます)

3. キーボードが接続できません。
キーボードが接続できない場合、次の手順に操作してください。
---- キーボードをフル充電してください。新しいAAAバッテリー2本をマウスにいれてください。
---- PCポートを変更して、USBレシーバーを差し込みしてください。
---- マウス及びお使用しているデバイスを再起動してください。
---- ほかのPC/ラップトップと接続して、動作しているかどうかを確認ください。
---- 上記の「ペアリング手順」をお読んで、「A：キーボード再ペアリング」または「B：マウス再ペアリング」の紹介に従って操作してください。
---- カスタマーサービスにお問い合わせください。

4. F1~F12機能しません
上記の「キーボード機能」をお読みください。

カスタマーサービス

Eメール：support@iclever.co.jp

iclever

Ultra Slim Full Size 2.4G Keyboard and Mouse Comb

IC-BK22 Combo

User Manual

www.iclever.co.jp

Thank you for choosing iClever! Please read this user manual carefully and save it for future reference.

Package Contents

1 x Wireless Keyboard
1 x Wireless Mouse
1 x Micro USB Charging Cable
1 x 2.4G USB Receiver
1 x User Manual
1 x Warranty Card

Specification of Keyboard

Dimensions	366 x 125 x 16,2 mm /14,4 x 4,9 x 0,64 in
Operating Range	< 10 m/32,8 ft
Charge Time	< 2 hours
Uninterrupted Work Time	90 hours
Lithium Battery Capacity	280 mAh
Key Life	3 million clicks
Standby Time	90 days

Specification of Mouse

Dimensions	107,5 x 60 x 27,5 mm / 4,23 x 2,36 x 1,08 in
Operating Range	< 10 m/32,8 ft
Power Source	2 x AAA Batteries (not included)
Uninterrupted Work Time	160 days
Button Life	3 million clicks
DPI	1000-1200-1600

Product Overview



① Power Switch: Push the switch to the right to turn on and to the left to turn off.
② Power Indicator: The power indicator will glow green for 3 seconds when the keyboard has been turned on successfully.
③ Caps Lock Indicator: The caps lock indicator will glow green when caps lock is activated. To turn off caps lock, press the caps lock button again.
(Note for Android users: keyboard does not include a caps lock indicator.)
④ Numeric Indicator: The numeric indicator will glow green when NumLock function is activated. To turn off NumLock, press the NumLock button again.
⑤ Fn Lock Indicator: Press keys of Fn + Esc to activate the Fn Lock function, and Fn Lock Indicator will turn to be blue. To close Fn Lock function, by pressing keys of Fn +Esc again, and Fn Lock Indicator will be off.
⑥ Charging Indicator: The charging indicator will glow red when the keyboard is charging and will turn off once fully charged.
⑦ Micro Charging Port: Used to charge the keyboard.



① ON/OFF Switch: turns the mouse on or turn off.
② Storage Slot: holds batteries (2 x AAA; not included) and stores the USB receiver.
③ DPI Switch:3 adjustable DPI(1000, 1200, 1600), to change it by pressing DPI Switch button.
④ Scroll Button: for Scrolling.

Keys and Functions

For system of windows and Mac OS X(Macbook/iMac), use function keys by pressing Fn+F1~F12 keys; use F1~F12 keys by directly pressing F1~F12 keys.
The table below describes special key combinations for different operating systems.

Function Keys	Fn+Windows	Windows	Fn+Mac OS X	Mac OS X
Way to use	Press Fn+	Press directly	Press Fn+	Press directly
Esc	Fn Lock	Esc	Fn Lock	Esc
F1	Brightness - (Windows 10)	F1	Brightness -	F1
F2	Brightness + (Windows 10)	F2	Brightness +	F2
F3	Web browser	F3	N/A	F3
F4	Search	F4	N/A	F4
F5	Calculator	F5	N/A	F5
F6	Previous track	F6	Previous track	F6
F7	Play/pause	F7	Play/pause	F7
F8	Next track	F8	Next track	F8
F9	Mute	F9	Mute	F9
F10	Volume -	F10	Volume -	F10
F11	Volume +	F11	Volume +	F11
F12	Screenshot	F12	Screenshot or N/A	F12

Note: Press " + " simultaneously to activate Fn Lock, and Fn Lock Indicator will turn to be blue. When Fn Lock is activated, pressing any of the key (F1 ~ F12) can activate the function.

Pairing Steps

Step 1. Plug the 2.4G USB receiver into the port of computer.
Step 2. Turn on the keyboard.
Step 3. Insert two of AAA battery into mouse (not included);turn on the mouse.
Step 4. Done. Ready to use.
Step 5. Choose your system by pressing Fn+Q/W to Mac or Windows system.

If connection fail, please read FAQ first, then to do as below steps:

A. Keyboard re-pairing:
Step 1. Turn on the keyboard.
Step 2. Press " + " keys meantime; the indicator will flash green quickly.
Step 3. Immediately plug the 2.4G USB receiver into the computer within 10s and keep the keyboard close to the receiver within 30cm (0.98 ft).
Note : Keep the keyboard off the ground.
Step 4. With the connection success, the power indicator will flash for 3 times then to be off.

B. Mouse re-pairing:
Step 1. Turn off the mouse and plug out the 2.4G USB receiver.
Step 2. Holding "mouse right key" and "scroll button" for 3s; then turn on the mouse.
Step 3. Immediately insert the receiver into the computer within 10s and keep the mouse close to the receiver within 30cm (0.98 ft).

Note: if re-pairing success, it is able to use. If failed, please repeat above steps again.

Sleep Mode

The keyboard and mouse will enter sleep mode if idle for 30 minutes. Press any key or move the mouse to exit sleep mode.

Charging for Keyboard

Step 1. Connect one end of the included USB cable to a USB charger, and connect the opposite end to the charging slot on the keyboard.
(Note: Output: DC 5.0 V / 500mA; USB charger is not included)
Step 2. The charging indicator will glow red while the keyboard is charging. A full charge takes approximately 2 hours.

Battery replace for Mouse

If the indicator light is not glowing, the batteries run out of power.Open the storage slot and replace the batteries.

FAQ

1. Can this keyboard work both in windows and Mac OS X system?

Yes, the keyboard work both in windows and Mac OS X. But under Mac OS X, function on are not working.
In addition, the function of , , is for Windows, and under Mac OS X, it is not working.

2. What is the mean of these keys , , , ?

Under windows system, it work as win, 無変換,変換 and NumLK (press Fn+W switching to Windows system)
Under Mac OS X system, it work as command, 英数, かな and clear (press Fn+Q switching to Mac OS X)

3. My keyboard fail to connect.
If your keyboard fail to connect, please try as following:
----Fully charge the keyboard and insert new two AAA batteries into the mouse.
----Change a computer port to insert the USB receiver.
----Restart the keyboard/mouse and your devices.
----Try to connect with other PC / laptop to test whether is working or not.
----Read above "Pairing Steps" and do as "A:keyboard re-pairing" or "B: Mouse re-pairing" introduce.
----Contact us.

4. Functions on F1~F12 are not working.
Please read above chart of "Keys and Functions".

Contact

For more questions, please contact us by support@iclever.co.jp